

# User Guide Easel Table



We want you to get the most out of your new playground equipment. We've compiled a few, simple notes to help proper use and maintenance of the equipment. As with all playground equipment, your own risk assessment is required as part of your school processes. Here are the key points:

- Chalkboard and Whiteboards require maintenance to avoid chalk and ink build up. Clean regularly with washing up liquid and a wet cloth, rinsing in between wiping the surface with the cloth.
- Sand down any rough areas of timber caused by weather or general use with a medium grade abrasive paper.
- Visually inspect your product, making sure no timbers are splitting and no fixings are loose and in accordance with your Pentagon Maintenance Manual

For more detailed maintenance information please refer to you Pentagon Maintenance Manual