


# User Guide - Sail Shade on Timber Posts (3.6M x 3.6M)



We want you to get the most out of your new playground equipment. We've compiled a few, simple notes to help proper use and maintenance of the equipment. As with all playground equipment, your own risk assessment is required as part of your school processes. Here are the key points:

- Your Shade Sail may be cleaned at any time using a solution of mild detergent and water. Apply the solution with a sponge or a very soft brush then rinse thoroughly with water from your hose.
- Periodically check all your fixing points and tensioning accessories to ensure they are in good condition and are not wearing down.
- Sand down any rough edges caused by weather or general use with a medium grade abrasive paper.
- Visually inspect your product, making sure no timbers are splitting and no fixings are loose and in accordance with your Pentagon Maintenance Manual

For more detailed maintenance information please refer to you Pentagon Maintenance Manual